

The V180 Laser Alignment System



System Components

- ① Display Unit
- ② Laser Units
- ③ Accessories



Alignment Procedure


- ① Display Unit Operation
- ② Set-up
- ③ Aim the Lasers
- ④ Entering Machine Dimensions
- ⑤ Taking Readings
- ⑥ Evaluate and Adjust: Vertical Plane
- ⑦ Evaluate and Adjust: Horizontal Plane
- ⑧ Check and Re-adjust
- ⑨ Document

1

Alignment
Procedure

Display Unit Operation

In addition to the On / Off button, only 4 buttons are required to operate the V180.




1

Alignment
Procedure

Display Unit Operation

The forward arrow button steps you through the alignment process.




1

Alignment
Procedure

Display Unit Operation

The back arrow button let's you go back to correct entry errors, or go back to an earlier step in the alignment.




1

Alignment
Procedure

Display Unit Operation

The + button:

- ➡ Used to enter values for machine dimensions.
 - ➡ Used to switch between Coupling Values Screen to Feet Values Screen.




1

Alignment
Procedure

Display Unit Operation

The - button:

- ➡ Used to adjust machine dimensions entered.
- ➡ Used to set the default to English Units.




1

Alignment
Procedure

Display Unit Operation

Setting measurement values in English units:



1

Alignment
Procedure

Display Unit Operation

Setting measurement values in English units:

“/mils

will be displayed in the upper right corner of the screen.


2

Alignment
Procedure

Set-up

Mount brackets on Shaft:

- 1 Drop chain into upside-down bracket.




2

Alignment
Procedure

Set-up

Mount brackets on Shaft:

- ② Flip bracket catching a chain link on the pin.




2

Alignment
Procedure

Set-up

Mount brackets on Shaft:

- ③ Flip bracket and set on shaft.
- ④ Bring chain around shaft.
- ⑤ Set dolly in the cradle.




2

Alignment
Procedure

Set-up

Mount brackets on Shaft:

- ⑥ Pull loose end of the chain tight around the shaft and re-seat the pin.




2

Alignment
Procedure

Set-up

Mount brackets on Shaft:

- ⑦ Tighten locking bolt.
- ⑧ Tighten 1/4 turn using Tightening Tool.



2


Alignment
Procedure

Set-up

- ⑨ Connect cables from the Laser Units to the Display Unit.

S to S

M to M




2

Alignment
Procedure

Set-up

Orientation



3

Alignment
Procedure

Aim the Lasers

- ① The laser units should be in the 12:00 position with detector covers closed exposing the targets.
- ② Turn the display unit on.




3

Alignment
Procedure

Aim the Lasers

- ③ Adjust the laser units until the laser beam from each unit hits near the center of the target on the opposite unit.




3

Alignment
Procedure

Aim the Lasers

- ④ To adjust the beams side to side, pivot the laser units on the rods.
- ⑤ To adjust the beams up and down, move the laser units up or down on the rods.




3

Alignment
Procedure

Aim the Lasers

⑥ Fine adjust with thumbwheel.





3

Alignment
Procedure

Aim the Lasers


- 7 Slide open the detector covers.



4

Alignment
Procedure

Entering Machine Dimensions





4

Alignment
Procedure

Entering Machine Dimensions

- 1 The “A” dimension will begin blinking on screen. This is the distance between score marks on top of the laser units. Measure the “A” dimension.




4


Alignment
Procedure

Entering Machine Dimensions

- ② Enter the “A” dimension using the + / - buttons.



- ③ Press the forward arrow button.





4

Alignment
Procedure

Entering Machine Dimensions

- ④ The “B” dimension will blink on the screen. This is the distance between score mark on top of the movable laser unit and the front feet of the movable machine. Measure the “B” dimension.




4


Alignment
Procedure

Entering Machine Dimensions

- ⑤ Enter the “B” dimension using the + / - buttons.



- ⑥ Press the forward arrow button.





4

Alignment
Procedure

Entering Machine Dimensions

- ⑦ The “C” dimension will blink on the screen. This is the distance between the feet of the movable machine. Measure the “C” dimension.




4


Alignment
Procedure

Entering Machine Dimensions

- ⑧ Enter the “C” dimension using the + / - buttons.



- ⑨ Press the forward arrow button.




5

Alignment
Procedure

Taking Readings

9, 3, 12 o'clock




5

Alignment Procedure

Taking Readings

- 1 A clock face appears on screen with a blinking dot at the 9:00 position. Rotate the shafts so the laser units are positioned at 9:00. Use the level to ensure the rods are horizontal.




5

Alignment
Procedure

Taking Readings

② Push the forward arrow button.




5

Alignment Procedure

Taking Readings

- ③ You will see a blinking dot at the 3:00 position by the clock face. Rotate the shafts 180 degrees until the laser units are positioned at 3:00. Use the level to ensure the rods are horizontal.




5

Alignment
Procedure

Taking Readings

④ Push the forward arrow button.




5

Alignment
Procedure

Taking Readings

- ⑤ You will see a blinking dot at the 12:00 position by the clock face. Rotate the shafts to bring the laser units to 12:00. Use the level to ensure the rods are vertical.




5

Alignment
Procedure

Taking Readings

⑥ Push the forward arrow button.




6

Alignment
Procedure

Evaluate and Adjust: Vertical Plane

- 1 The Coupling Values Screen for the vertical plane is now displayed.




6

Alignment
Procedure

Evaluate and Adjust: Vertical Plane

- ② Press the + button for the feet values screen.




6

Alignment
Procedure

Evaluate and Adjust: Vertical Plane

- ③ The Feet Values Screen for the vertical plane is now displayed.



Front feet are low,
add 10 mil (0.010")

shim

Back feet are high,
remove 30 mil

(0.030") shim.

6

Alignment
Procedure


Evaluate and Adjust: Vertical Plane

- ➡ Positive values at the feet mean that the movable machine is high.
- ➡ Negative values at the feet mean that the movable machine is low.


6

Alignment
Procedure


Evaluate and Adjust: Vertical Plane



Coupling Values



Feet Values



















6

Alignment
Procedure

Evaluate and Adjust: Vertical Plane

④ Evaluating angularity and offset.


<i>Coupling Value Symbols</i>		<i>Shaft Centerlines</i>		<i>Feet Position</i>	
<i>Angularity</i>	<i>Offset</i>	<i>Stationary</i>	<i>Moveable</i>	<i>Front</i>	<i>Rear</i>
 <i>and</i> 				High	High
 <i>and</i> 				High or Low*	High or Low*
 <i>and</i> 				High or Low*	High or Low*
 <i>and</i> 				Low	Low

7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane

- 1 Push the forward arrow button.




7

Alignment Procedure

Evaluate and Adjust: Horizontal Plane

- ② You will see a blinking dot at the 3:00 position by the clock face. Rotate the shafts 90 degrees until the laser units are positioned at 3:00. Use the level to ensure the rods are horizontal.




7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane

③ Push the forward arrow button.




7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane

- ④ The Coupling Values Screen for the horizontal plane is now displayed.




7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane

- ⑤ Press the + button for the feet values screen.




7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane

- ⑥ The Feet Values Screen for the horizontal plane is now displayed.



Front feet: move away
from the operator 1.6

Back feet: move
towards the operator
7.5 mils.

7

Alignment Procedure


Evaluate and Adjust: Horizontal Plane

- ➡ Positive values at the feet mean that the movable machine is away from the operator.
- ➡ Negative values at the feet mean that the movable machine is towards the operator.


7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane



Feet Values



















7

Alignment
Procedure

Evaluate and Adjust: Horizontal Plane

⑦ Evaluating angularity and offset.


<i>Coupling Value Symbols</i>		<i>Shaft Centerlines</i>		<i>Feet Position</i>	
<i>Angularity</i>	<i>Offset</i>	<i>Stationary</i>	<i>Moveable</i>	<i>Front</i>	<i>Rear</i>
 and 				Away	Away
 and 				Away or Towards*	Away or Towards*
 and 				Away or Towards*	Away or Towards*
 and 				Towards	Towards

8

Alignment
Procedure

Check and Re-adjust

- 1 Push the forward arrow button.




8

Alignment
Procedure

Check and Re-adjust

- ② You will see a blinking dot at the 12:00 position by the clock face. Rotate the shafts to bring the laser units to 12:00.




8

Alignment
Procedure

Check and Re-adjust

③ Push the forward arrow button.



8

Alignment Procedure

Check and Re-adjust

- ➡ The Coupling Values Screen for the vertical plane re-appears with the angularity and offset values now changed to reflect any machine moves.
- ➡ You can now proceed through the alignment screens to check and re-adjust as necessary.
- ➡ You can also use the forward and backward arrow buttons to toggle back and forth between horizontal and vertical readings.
- ➡ The laser units have to be oriented accordingly at 12:00 or 3:00. Follow the on-screen clock face indicator.

9

Alignment
Procedure

Document

- 1 Use the V180 Laser Alignment Report form to document your alignment findings



The image shows a VIBRALIGN V180 Laser Alignment Report form. The form is titled "VIBRALIGN V180 Laser Alignment Report". It includes fields for "Equipment Name:", "Location:", "Aligned By:", "Date/Time:", "Identification:", and "APPROVED:". Below these fields are "Enter Dimensions: A =", "B =", and "C =". The form is divided into two main sections: "INITIAL CONDITION" and "FINAL (ALIGNED) CONDITION". Each section contains two sub-sections: "Initial Vertical Values" and "Initial Horizontal Values" for the top section, and "Final Vertical Values" and "Final Horizontal Values" for the bottom section. Each sub-section includes a diagram of a shaft with a laser sensor, a "Check Symbol" (a square with a plus sign), a "Check Symbol" (a square with a minus sign), and a "Check Symbol" (a square with a plus sign). The form also includes fields for "Foot Position" and "Rear Foot" for each sub-section.

9

Alignment
Procedure

Document

② Date / Time / Machine / Dimensions.



Laser Alignment Report

Date/Time: _____

Equipment Name: _____

Identification: _____

Location: _____

RPM/HP: _____

Aligned By: _____

Enter Dimensions: A = _____ B = _____ C = _____

9

Alignment
Procedure

Document

③ Initial condition.

INITIAL CONDITION

Initial Vertical Values

Check Symbol:	Angular (Mils/In.):	Offset (Mils):	Check Symbol:
<input type="checkbox"/>			<input type="checkbox"/>
<input type="checkbox"/>			<input type="checkbox"/>

Foot Positions:

Front Feet: _____ Mils. Rear Feet: _____ Mils.

Initial Horizontal Values

Check Symbol:	Angular (Mils/In.):	Offset (Mils):	Check Symbol:
<input type="checkbox"/>			<input type="checkbox"/>
<input type="checkbox"/>			<input type="checkbox"/>

Foot Positions:

Front Feet: _____ Mils. Rear Feet: _____ Mils.


9

Alignment
Procedure

Document

④ Final (Aligned) Condition.

FINAL (ALIGNED) CONDITION




Final Vertical Values

Check Symbol:	Angular (Mils/In.):	Offset (Mils):	Check Symbol:
<input type="checkbox"/>			<input type="checkbox"/>
<input type="checkbox"/>			<input type="checkbox"/>

Foot Positions:

Front Feet: _____ Mils. Rear Feet: _____ Mils.



Final Horizontal Values

Check Symbol:	Angular (Mils/In.):	Offset (Mils):	Check Symbol:
<input type="checkbox"/>			<input type="checkbox"/>
<input type="checkbox"/>			<input type="checkbox"/>

Foot Positions:

Front Feet: _____ Mils. Rear Feet: _____ Mils.

1

System
Components

Display Unit



1

System
Components

Display Unit

Contains the alignment computer



1

System
Components

Display Unit

On / Off button




1

System
Components

Display Unit

Keypad for data entry




1

System
Components

Display Unit

LCD Display




1

System
Components

Display Unit

Stationary and Movable Cable Ports



1

System Components

Display Unit


- ➡ Runs on 3 C-cell batteries
- ➡ Is rugged, but:
 - ✓ Care must be taken not to drop the Display Unit
 - ✓ Do not get the Display Unit wet



2

System
Components

Laser Units




2

System
Components

Laser Units

Stationary



Movable





2

System
Components

Laser Units

Laser Unit cables attach to the
Display Unit





2

System
Components

Laser Units

- ➡ Attach to the Brackets
- ➡ Brackets attach to the machine shaft





2

System
Components

Laser Units

Protective Cover





2

System
Components

Laser Units

Coarse Adjustment





2

System
Components

Laser Units

Fine Adjustment




2

System
Components

Laser Units

Emit Laser Radiation




3

System
Components

Accessories

19" Chain with Tightening Nut




3

System
Components

Accessories

Measuring Tape with Level



3


System
Components

Accessories

Tightening Tool



Rubber Cable Holder



Pre-Alignment



- ① Check run out
- ② Check pipe strain
- ③ Correct gross soft foot
- ④ Rough alignment
- ⑤ Check hub separation
- ⑥ Record tightening sequence

1

Pre-Alignment

Check run out

① Set up the dial indicator



The dial indicator plunger contacts the hub or shaft to be checked.

It is affixed to any point in space: the machine base, a bearing housing, the adjacent coupling hub (if the coupling is “broken”).

1

Pre-Alignment

Check run out

② Measure run out

The shaft to be checked is rotated until the dial indicator reaches a maximum: (+ or -).

The dial indicator is adjusted to zero.

The shaft is rotated again until the dial indicator reaches a maximum: (+ or -). This is the run out value.

Checking Run Out	If	Then
Driven Side coupling run out	.002" or less	Driven side OK, go to driver side coupling
	greater than .002"	Check shaft run out
shaft run out	.001" or less	Shaft OK, coupling is eccentric
	greater than .001"	Shaft is bent
Driver Side coupling run out	.002" or less	Run out check completed.
	greater than .002"	Check shaft run out
shaft run out	.001" or less	Shaft OK, coupling is eccentric
	greater than .001"	Shaft is bent

2

Pre-Alignment

Check pipe strain

- ① Dial indicator set up as in checking run out.
- ② Loosen flange bolts to check the effect of pipe strain.

Checking Pipe Strain	If	Then
Suction Flange	Dial indicator changes at 12:00 or 3:00 are: .002" or less	Check discharge flange
	greater than .002"	Excessive pipe strain
Discharge Flange	Dial indicator changes at 12:00 or 3:00 are: .002" or less	Pipe strain check completed.
	greater than .002"	Excessive pipe strain

3


Pre-Alignment

Soft foot


Soft foot occurs when machine feet do not rest flatly on the machine base.

Soft foot is caused by deformed machine base plates or by deformed machine feet.

Short foot



Angled foot




3

Pre-Alignment

Correct gross soft foot

- ① Loosen all mounting bolts.
- ② Find any loose shim packs.
- ③ Correct by adding to loose shim packs.



4

Pre-Alignment


Rough alignment

➡ Angular misalignment

Find the gap difference.

Vertical misalignment:
measure gap difference
top and bottom.

Horizontal misalignment:
measure side to side.



You may use calipers, an inside micrometer, feeler gauges, or an indicator on the coupling face.

4

Pre-Alignment

Rough alignment

➡ Angular misalignment

Calculate the correction

Angular correction:

$$\frac{\text{gap difference}}{\text{coupling diameter}} \times \text{distance between bolt centers}$$

Vertical misalignment

- If the gap is wider at the top:
remove shims from front feet **or** add to the rear feet.
- If gap is wider at bottom:
Add to front feet or remove from rear feet..


4

Pre-Alignment

Rough alignment

➡ Offset misalignment

Use a straight edge to correct vertical and horizontal offset misalignment.




5

Pre-Alignment

Check hub separation

Compare the final gap reading (last section) to the coupling manufacturer's tolerance.




6

Pre-Alignment

Record tightening sequence.

Follow the sequence throughout the alignment.





The V180 Laser Alignment System





Introduction


- ① *Measurement Principles*
- ② *Laser Accuracy and Sensitivity*
- ③ *The Alignment Process*



The V180 Laser Alignment System

Measuring Principles

Designed to achieve precision alignment of two horizontally mounted machines






The V180 Laser Alignment System

Measuring Principles

Based on the reverse indicator alignment method






The V180 Laser Alignment System

Measuring Principles

Based on the reverse indicator alignment method






The V180 Laser Alignment System

Measuring Principles

Shaft positions are expressed in two measurements:


Offset misalignment





Measuring Principles

Angular misalignment






The V180 Laser Alignment System

Laser accuracy and Sensitivity

Can measure deviation as small as 1 micron






The V180 Laser Alignment System

Laser accuracy and Sensitivity

The V180 displays values in 1/10,000 of an inch





The Alignment Process


- Measurement
- ②Alignment
- ③Documentation



The V180 Laser Alignment System

The Alignment Process

Measurement...determines the existing position of the two shafts to be aligned.





The Alignment Process

Measurement with the V180:


- ➡ Both angularity and offset are expressed as numerical values.
- ➡ The V180 requires no graphing or calculating.
- ➡ The technician inputs movable machine dimensions.
- ➡ Then takes three readings (at 9, 3 and 12:00)
- ➡ The V180 precisely measures angularity and offset at the coupling in both vertical and horizontal planes.



The V180 Laser Alignment System

The Alignment Process

Alignment...moving the moveable machine to bring the shafts into alignment.





The Alignment Process

- ➡ The V180 calculates the angularity and offset readings and displays movement at the feet.
- ➡ Foot values are live on-screen. The values will change to reflect feet position as the technician moves the machine.
- ➡ As the foot values approach zero, the technician can toggle to the coupling values screen to see if the moves have brought the angularity and offset values into tolerance.



The V180 Laser Alignment System

The Alignment Process

➡ Manufacturers generally provide alignment tolerances for their equipment. The tolerance is dependent upon operating speed (rpm). The table provides general alignment tolerance guidelines.

<i>Machine Speed</i>	<i>Angularity in Mils/Inch (Thousandths/Inch)</i>	<i>Offset in Mils or Thousandths</i>
3600	.5/1"	2.0
1800	.7/1"	4.0
1200	1.0/1"	6.0
900	1.5/1"	8.0



The V180 Laser Alignment System

The Alignment Process

Documentation...recording the alignment conditions before and after precision alignment.

The form is titled "VIBRALIGN V180 Laser Alignment Report". It includes fields for "Equipment Name:", "Location:", "Aligned By:", "Date/Time:", "Modification:", and "APPROVED:". Below these is a section for "Enter Dimensions:" with fields for A, B, and C. The form is divided into two main sections: "INITIAL CONDITION" and "FINAL (ALIGNED) CONDITION". Each section contains two sub-sections: "Initial Vertical Values" and "Initial Horizontal Values" (or "Final Vertical Values" and "Final Horizontal Values" for the final condition). Each sub-section includes a diagram of a machine with a laser line, a "Check Symbol" field, a "Check Symbol" field, and "Foot Positions" for "Front Foot" and "Rear Foot".